


Lock De-icer

HOT KEY INSTRUCTIONS



To USE:

- Slide the On/Off button forward until de-icer rod it fully exposed. Rod will immediately get warm.
- 2) Incert de-icer into frozen lock. Do not turn while in lock.
- After 30 seconds remove from lock and silde the on/off button down unitl rod is no longer exposed.

WARNING

Rod get extremely hot, do not ever touch the rod.

BATTERY INSTALLATION

- 1) Open the battery cover
- 2) Correctly the insert 2 x AAA batteries
- 3) Replace the cover
- 4) Do not mix old and new batteries
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel cadmium) batteries

NOTE

If light begins to weaken, please replace batteries.